



Collect

LASER CARTRIDGE VACIOS

Código	Description
V-AP-M1960G/A	APPLE M1960G/A (XEROX XP5) (V)
V-AP-M5893G/A	APPLE W8500 / INFOPRINT 20 (V)
V.BRO.DR200-250-300	<i>BROTHER DR-200 / DR-250 / DR300 DRUM (V)</i>
V-BRO-DR350	BROTHER DR-350 / DR-2000 DRUM (V)
V-BRO-DR360	BROTHER DR-360 / DR-2100 DRUM (V)
V-BRO-DR400	BROTHER DR-400 / DR-6000 DRUM (V)
V-BRO-DR500	BROTHER DR-500 / DR-7000 DRUM (V)
V-BRO-DR510	BROTHER DR-510 / DR-3000 DRUM (V)
V-BRO-DR520	BROTHER DR-520 / DR-3100 DRUM (V)
V-BRO-DR600	BROTHER DR-600 / DR-4000 DRUM (V)
VL-BRO-DR700	BROTHER DR-700 / DR-5500 DRUM (V)
VL-BRO-TN04C	BROTHER TN04 C (V)
VL-BRO-TN04K	BROTHER TN04 K (V)
VL-BRO-TN04M	BROTHER TN04 M (V)
VL-BRO-TN04Y	BROTHER TN04 Y (V)
VL-BRO-TN110C	BROTHER TN110 C (V)
VL-BRO-TN110K	BROTHER TN110 K (V)
VL-BRO-TN110M	BROTHER TN100 M (V)
VL-BRO-TN110Y	BROTHER TN110 Y (V)
VL-BRO-TN115C	BROTHER TN115 C (V)
VL-BRO-TN115K	BROTHER TN115 K (V)
VL-BRO-TN115M	BROTHER TN115 M (V)
VL-BRO-TN115Y	BROTHER TN115 Y (V)
VL-BRO-TN330	BROTHER TN-330 / TN-360 / TN-2110 (V)
VL-BRO-TN350	BROTHER TN-350 / TN-2000 (V)
VL-BRO-TN460	<i>BROTHER TN-430 / 460 / TN-6600 (V)</i>
VL-BRO-TN530	<i>BROTHER TN-530 / TN-560 / TN-7600 (V)</i>
VL-BRO-TN540	<i>BROTHER TN-540 / TN-570 / TN-3030 (V)</i>
VL-BRO-TN580	BROTHER TN-550 / TN-580 / TN-3130 (V)
VL-CA-104	CANON 104 / FX9 / FX10 (V)
VL-CA-106	CANON 106 (V)
VL-CA-E40	CANON E-40 (V)
VL-CA-FX11	CANON FX11 (V)
VL-CA-FX8	CANON FX8 (V)
VL-CA-L50	CANON L-50 (V)
VL-CA-S35	CANON S35 (V)
VL-CA-X25	CANON X25 (V)
VL-DELL-1100	DELL 1100 (V)
VL-DELL-1125	DELL 1125 / MINOLTA 1400 (V)
VL-DELL-1125DR	DELL 1125 / MINOLTA 1400 DRUM (V)
VL-DELL-1815	DELL 1815 (V)
VL-DELL-3110 C	DELL 3110 C / PHASER 6180 C (V)
VL-DELL-3110 K	DELL 3110 K / PHASER 6180 K (V)
VL-DELL-3110 M	DELL 3110 M / PHASER 6180 M (V)
VL-DELL-3110 Y	DELL 3110 Y / PHASER 6180 Y (V)

VL-DELL-5330	DELL 5330 (V)
VL-HP-92298A	HP 98A / EX (V)
VL-HP-92298X	HP 98X / EX (V)
VL-HP-C3903A	HP 03A / VX - NON GLUED (V)
VL-HP-C3906A	HP 06A / AX (V)
VL-HP-C3909A	HP 09A / WX (V)
VL-HP-C3909X	HP 09X / WX (V)
VL-HP-C4092A	HP 92A / 1100 (V)
VL-HP-C4096A	HP 96A / 2100 (V)
VL-HP-C4127A	HP 27A / 4000 (V)
VL-HP-C4127X	HP 27X / 4000 (V)
VL-HP-C4129X	HP 29X / 5000 (V)
VL-HP-C4182X	HP 82X / 8100 (V)
VL-HP-C8061A	HP 61A / 4100 (V)
VL-HP-C8061X	HP 61X / 4100 (V)
VL-HP-C8543X	HP 43X / 9000 (V)
VL-HP-C9720A	HP C9720A / 4600 K (V) (07/08/09)
VL-HP-C9721A	HP C9721A / 4600 C (V) (07/08/09)
VL-HP-C9722A	HP C9722A / 4600 Y (V) (07/08/09)
VL-HP-C9723A	HP C9723A / 4600 M (V) (07/08/09)
VL-HP-C9730A	HP C9730A / 5500 K (V) (07/08/09)
VL-HP-C9731A	HP C9731A / 5500 C (V) (07/08/09)
VL-HP-C9732A	HP C9732A / 5500 Y (V) (07/08/09)
VL-HP-C9733A	HP C9733A / 5500 M (V) (07/08/09)
VL-HP-CB435A	HP 35A / P1005 (V) NON STARTER
VL-HP-CB435AI	HP 35A / P1005 STARTER (V)
VL-HP-CB436A	HP 36A / P1505 (V) NON STARTER
VL-HP-CB436AI	HP 36A / P1505 STARTER (V)
VL-HP-CB540A	HP CB540A / CP1215 K (V) NON STARTER
VL-HP-CB541A	HP CB541A / CP1215 C (V) NON STARTER
VL-HP-CB542A	HP CB542A / CP1215 Y (V) NON STARTER
VL-HP-CB543A	HP CB543A / CP1215 M (V) NON STARTER
VL-HP-CB540A	HP CB540A / CP1215 K (V) STARTER
VL-HP-CB541A	HP CB541A / CP1215 C (V) STARTER
VL-HP-CB542A	HP CB542A / CP1215 Y (V) STARTER
VL-HP-CB543A	HP CB543A / CP1215 M (V) STARTER
VL-HP-CC364A	HP 64A / P4015 (V)
VL-HP-CC364X	HP 64X / P4015 (V)
VL-HP-CC530A	HP CC530A / 2320 K (V) NON STARTER
VL-HP-CC531A	HP CC531A / 2320 C (V) NON STARTER
VL-HP-CC532A	HP CC532A / 2320 Y (V) NON STARTER
VL-HP-CC533A	HP CC533A / 2320 M (V) NON STARTER
VL-HP-CC530A	HP CC530A / 2320 K (V) STARTER
VL-HP-CC531A	HP CC531A / 2320 C (V) STARTER
VL-HP-CC532A	HP CC532A / 2320 Y (V) STARTER
VL-HP-CC533A	HP CC533A / 2320 M (V) STARTER
VL-HP-CE250A	HP CE250A / CP3525 NON STARTER
VL-HP-CE251A	HP CE251A / CP3525 C (V) NON STARTER
VL-HP-CE252A	HP CE252A / CP3525 M (V) NON STARTER
VL-HP-CE253A	HP CE253A / CP3525 Y (V) NON STARTER
VL-HP-CE250X	HP CE250X / CP3525 HIGH YIELD
VL-HP-CE250A	HP CE250A / CP3525STARTER
VL-HP-CE251A	HP CE251A / CP3525 C (V) STARTER
VL-HP-CE252A	HP CE252A / CP3525 M (V) STARTER
VL-HP-CE253A	HP CE253A / CP3525 Y (V) STARTER
VL-HP-CE505AI	HP 05A / P2035/55 (V) STARTER

VL-HP-CE505XI	HP 05X / P2035/55 (V) STARTER
VL-HP-CE505A	HP 05A / P2035/55 (V) NON STARTER
VL-HP-CE505X	HP 05X / P2035/55 (V) NON STARTER
VL-HP-Q1338A	HP 38A / 4200 (V)
VL-HP-Q1339A	HP 39A / 4300 (V)
VL-HP-Q2612A	HP 12A / 1010 (V)
VL-HP-Q3960A	HP Q3960A / 2550 K (V)
VL-HP-Q3961A	HP Q3961A / 2550 C (V)
VL-HP-Q3962A	HP Q3962A / 2550 Y (V)
VL-HP-Q3963A	HP Q3963A / 2550 M (V)
VL-HP-Q5942A	HP 42A / 4250 (V)
VL-HP-Q5942X	HP 42X / 4250 (V)
VL-HP-Q5945A	HP 45A / 4345 (V)
VL-HP-Q5949A	HP 49A / 1320 (V)
VL-HP-Q5949X	HP 49X / 1320 (V)
VL-HP-Q6000A	HP Q6000A / 2600 K (V)
VL-HP-Q6001A	HP Q6001A / 2600 C (V)
VL-HP-Q6002A	HP Q6002A / 2600 Y (V)
VL-HP-Q6003A	HP Q6003A / 2600 M (V)
VL-HP-Q6470A	HP Q6470A / 3600-3800 K (V)
VL-HP-Q6471A	HP Q6471A / 3600 C (V)
VL-HP-Q6472A	HP Q6472A / 3600 Y (V)
VL-HP-Q6473A	HP Q6473A / 3600 M (V)
VL-HP-Q6511A	HP 11A / 2420 (V)
VL-HP-Q6511X	HP 11X / 2420 (V)
VL-HP-Q7516A	HP 16A / 5200 (V)
VL-HP-Q7551A	HP 51A / P3005 (V)
VL-HP-Q7551X	HP 51X / P3005 (V)
VL-HP-Q7553A	HP 53A / P2015 (V)
VL-HP-Q7553X	HP 53X / P2015 (V)
VL-HP-Q7570A	HP Q7570A / M5025/35 (V)
VL-HP-Q7581A	HP Q7581A / 3800 C (V)
VL-HP-Q7582A	HP Q7582A / 3800 Y (V)
VL-HP-Q7583A	HP Q7583A / 3800 M (V)
VL-IBM-63H3005	IBM 4312 / XEROX P12 (V)
VL-IBM-90H0748	IBM INFOPRINT 20 (V)
VL-LEX-08A0478	LEXMARK E320 / IBM 1116 (V)
VL-LEX-12035SA	LEXMARK E120 (V)
VL-LEX-1382925	LEXMARK OPTRA S (V)
VL-LEX-12A5845	LEXMARK OPTRA T (V)
VL-LEX-12A6835	LEXMARK T520 / IBM 1120 (V)
VL-LEX-12A6865	LEXMARK T620 / IBM 1130 (V)
VL-LEX-12A7405	LEXMARK E321 / DELL P1500 (V)
VL-LEX-12A7415	LEXMARK T420 / IBM 1222 / DELL 2500 (V)
VL-LEX-12A7460	LEXMARK T630 / IBM 1332 / DELL 5200 (V)
VL-LEX-12A7465	LEXMARK T632 / DELL 5300 (V)
VL-LEX-12A8302	LEXMARK E330 / DELL 1700 DRUM (V)
VL-LEX-12A8400	LEXMARK E330 / IBM 1412 / DELL 1700 (V)
VL-LEX-12A8425	LEXMARK T430 / DELL 1422 (V)
VL-LEX-17G0154	LEXMARK OPTRA M410 (V)
VL-LEX-64015SA	LEXMARK T640 / IBM 1532 / DELL 5210 (V)
VL-LEX-64415XA	LEXMARK T644 / IBM 1552 / DELL 5310 (V)
VL-LEX-E250A21A	LEXMARK E250 / IBM 1622 / DELL 1720 (V)
VL-LEX-E250X22G	LEXMARK E250 / DELL1720 DRUM UNIT (V)
VL-LEX-E260A21A	LEXMARK E260/360/460 (V)
VL-LEX-E260X22G	LEXMARK E260/360/460 DRUM UNIT (V)

VL-LEX-T650	LEXMARK T650 (V)
V- OKI-6300	OKIDATA B6300
VL-OKI-4100DR	OKIDATA B4100-4300 DRUM UNIT (V)
VL-PAN-UG3204	PANASONIC UG-3204 / APPLE 1960 (V)
VL-PAN-UG3313	PANASONIC UG-3313 (V)
VL-PAN-UG3350	PANASONIC UG-3350 (V)
VL-PAN-UG5510	PANASONIC UG-5510 (V)
VL-PAN-UG5520	PANASONIC UG-5520 (V)
VL-SAM-CLP500	SAMSUNG CLP-500 K/C/M/Y (V)
VL-SAM-CLP510	SAMSUNG CLP-510 K/C/M/Y (V)
VL-SAM-CLP600	SAMSUNG CLP-600 K/C/M/Y (V)
VL-SAM-ML1610	SAMSUNG ML-1610 (V)
VL-SAM-ML2010	SAMSUNG ML-2010 (V)
VL-SAM-ML2850	SAMSUNG ML-2850
VL-SAM-ML3050	SAMSUNG ML-3050 (V)
VL-SAM-SCX4521D3	SAMSUNG SCX-4521 (V)
VL-SAM-SCX4720	SAMSUNG SCX-4720 (V)
VL-SAM-SCX4725	SAMSUNG SCX-4725 / PHASER 3200 (V)
VL-SH-AL100 DR	SHARP AL-100DR DRUM UNIT (V)
VL-SH-AL100TD	SHARP AL-100TD (V)
VL-SH-AL80TD	SHARP AL-80TD (V)
VL-SH-FO45DR	SHARP FO45DR DRUM UNIT (V)
V- XE 106R01159	XEROX 3117 - 3122
V-XE 109R00725	XEROX 3120 -3130 -3121
V-XE 109R00747	XEROX 3150
V-XE 106R01246	XEROX 3428
V-XE 106R00688	XEROX 3450
VL-XE-016-1944-00	XEROX PHASER 7700 C (V)
VL-XE-016-1945-00	XEROX PHASER 7700 M (V)
VL-XE-016-1946-00	XEROX PHASER 7700 Y (V)
VL-XE-016-1947-00	XEROX PHASER 7700 K (V)
VL-XE-101R203	XEROX WC PRO 635 / TOSHIBA DK10 (V)
VL-XE-106R00552	XEROX PHASER 7750 K (V)
VL-XE-106R00553	XEROX PHASER 7750 C (V)
VL-XE-106R00554	XEROX PHASER 7750 M (V)
VL-XE-106R00555	XEROX PHASER 7750 Y (V)
VL-XE-106R01160	XEROX PHASER 7760 C (Y)
VL-XE-106R01161	XEROX PHASER 7760 M (Y)
VL-XE-106R01162	XEROX PHASER 7760 Y (Y)
VL-XE-106R01163	XEROX PHASER 7760 K (Y)
VL-XE-106R1047	XEROX M20 / SAM 6220/6320 (V)
VL-XE-106R482	XEROX XL2120 (V)
VL-XE-106R584	XEROX WC PRO 412 (V)
VL-XE-113R00627	XEROX PHASER 4400 (V)
VL-XE-113R00663	XEROX M15 / SAMSUNG M15I DRUM
VL-XE-113R00711	XEROX PHASER 4510 / OKI 6500 (V)
VL-XE-113R459	XEROX WC PRO 665 / TOSHIBA DP 120
VL-XE-113R657	XEROX PHASER 4500 (V)
VL-XE-113R671	XEROX M20 / SAM 6220/6320 DRUM (V)
VL-XE-13R00621	XEROX WC PE220 (V)
VL-XE-13R544	XEROX XC830 DRUM UNIT (V)
VL-XE-13R551	XEROX XD100 DRUM UNIT (V)
VL-XE-6R881	XEROX XC800 (V)
VL-XE-6R914	XEROX XD100 TONER (V)
VL-XE-6R916	XEROX XE80 / SHARP FO26ND (V)